

USER MANUAL AND MAINTENANCE



SERIES PUMA | PUMA ACD | PUMA DEX 1/3D | PUMA DEX 1/2D

TRANSLATION OF ORIGINAL INSTRUCTIONS

Rev. 04, March 1, 2026

Depureco Industrial Vacuums Srl

Company subject to management and coordination COFISE spa

Via Venezia, 32 - 10088 Volpiano (TO)

Tel. +39 011 98.59.117

Fax. +39 011 98.59.326

www.depureco.com

depureco@depureco.com

depureco@documentipec.com

C.F. and P.I. 02258610357 - **Capital stock:** € 25,000 i.v.

Turin Business Register - **R.E.A.** TO-1149668

Registration **WEEE** No. IT18090000010711



INDEX

1. INFORMATION SECTION	9
1.1. Preface	9
1.2. Identification of major parts	11
1.3. Optional parts	12
1.4. Manufacturer identification data	12
1.5. Name plate	12
1.6. Intended uses	12
1.7. ATEX Marking	14
1.8. Allowable environmental conditions	14
1.9. Noise level	15
1.10. Technical Data	17
1.11. Warranty	28
2. SAFETY SECTION	29
2.1. Safety information	29
2.2. Safety prescriptions	29
2.3. ATEX Safety Instructions	32
2.4. Safety plates and symbols	34
2.5. Residual risks	37
2.6. Directives applied	37
3. HANDLING, UNPACKING AND INSTALLATION SECTION	38
3.1. Handling	38
3.2. Unpacking	39
3.3. Installation	40
4. OPERATION SECTION	42
4.1. Command description	42
4.2. Duty cycle	43
4.3. Air speed control	45
4.4. Filter cleaning cycle	45
4.5. Emptying the container	47
4.6. Inserting and locking the container	49
4.7. Storage - decommissioning	49



5. MAINTENANCE SECTION	50
5.1. Informational Notes	50
5.2. General safety standards	50
5.3. Primary filter replacement	52
5.4. HEPA filter replacement	62
5.5. If something doesn't work	64
5.6. Scrapping	64





DECLARATION OF CONFORMITY FOR NON ATEX VERSIONS

PUMA 10 - PUMA 15 - PUMA 18 - PUMA 20 - PUMA 25 - PUMA 30 - PUMA 35-

**PUMA 10 ACD - PUMA 15 ACD - PUMA 18 ACD - PUMA 20 ACD - PUMA 25 ACD -
PUMA 30 - PUMA 35**



DECLARATION OF COMPLIANCE

The manufacturer:

DEPURECO INDUSTRIAL VACUUMS S.r.l. – Via Venezia, 32 – 10088 Volpiano (TO) – ITALY |

Phone. +39 011 98 59 117 – Fax + 39 011 98 59 326 – Tax code. | VAT REG. NO.

02258610357

e-mail: depureco@depureco.com – www.depureco.com

hereby declares

under their sole responsibility that the vacuum cleaner model described in this manual



To which this declaration refers, complies with the essential safety requirements provided by the Machinery Directive 2006/42/EC, the Directive 2014/30/EU regarding Electromagnetic Compatibility and the Directive 2011/65/EU - ROHS - regarding restriction of the use of certain hazardous substances in electrical and electronic appliances.

The conformity has been verified in accordance with the requirements mentioned by the Standards:

EN 60335-1

EN IEC 61000-3-2:2019

EN IEC 63000:2018

EN 60335-2-69

EN 55014-2:2015

The Harmonised Standards applied for the design, manufacture and testing of the vacuum cleaner are listed in a technical file stored at the technical department of DEPURECO S.r.l. premises.

The production control was carried out by Notified Body No. **0474 RINA Services S.p.a.**

This declaration shall become invalid if modifications on the vacuum cleaner are carried out without approval from the manufacturer.

First issue: 15 June 2019

Revision 01: 16 October 2023

Revision 02: 26 April 2024


The Legal Representative
Marco Devincentis

Depureco Industrial Vacuums Srl
Società soggetta a direzione e coordinamento COHSE spa

PERFORMANCE ON VACUUM SINCE 1972

Via Venezia, 32 - 10088 Volpiano (TO)
Tel. +39 011 98.59.117
Fax +39 011 98.59.326

www.depureco.com
depureco@depureco.com
depureco@documentipeccom

C.F. e P.I. 02258610357
Registro Imprese di Torino - R.E.A. TO-1149668
Capitale Sociale: € 25.000 i.v.



DECLARATION OF CONFORMITY FOR ATEX VERSIONS

PUMA 10 DEX 1/3D - PUMA 15 DEX 1/3D - PUMA 20 DEX 1/3D -

PUMA 25 DEX 1/3D - PUMA 30 P DEX 1/3D - PUMA 30 S DEX 1/3D



DECLARATION OF COMPLIANCE

The manufacturer:

DEPURECO INDUSTRIAL VACUUMS S.r.l. – Via Venezia, 32 – 10088 Volpiano (TO) – ITALY | Phone. +39 011 98 59 117 – Fax + 39 011 98 59 326 – Tax code. | VAT REG. NO. 02258610357

e-mail: depureco@depureco.com – www.depureco.com

hereby declares

under their sole responsibility that the vacuum cleaner model described in this manual



To which this declaration refers, complies with the essential safety requirements provided by the Machinery Directive 2006/42/EC, the Directive 2014/30/EU regarding Electromagnetic Compatibility, the Directive 2011/65/EU - ROHS - regarding restriction of the use of certain hazardous substances in electrical and electronic appliances and by the ATEX Directive 2014/34/EU with the following details.

The conformity has been verified in accordance with the requirements mentioned by the Standards:

UNI EN 1127-1:2019 UNI EN ISO 80079-36:2016 EN 60079-0:2018 EN60079-31:2014

Making :  0474  II 1/3 D Ex htc IIIC T140°C Da/Dc

The Notified Body TÜV Nord issued the EU Type Certificate: TÜV CY 21 ATEX 0206460 X

The production check was carried out by Notified Body No. 0474 RINA Services S.p.a.

The Harmonised Standards applied for the design, manufacture and testing of the vacuum cleaner are listed in a technical file stored at the technical department of DEPURECO S.r.l. premises.
This declaration shall become invalid if modifications on the vacuum cleaner are carried out without approval from the manufacturer.

First issue: 15 June 2019

Revision 01: 16 October 2023.

The Legal Representative
Marco Devinentis CEO

Depureco Industrial Vacuums Srl
Società soggetta a direzione e coordinamento COFISE spa

PERFORMANCE ON VACUUM SINCE 1972

Via Venezia, 32 - 10088 Volpiano (TO)
Tel. +39 011 98.59.117
Fax +39 011 98.59.326

www.depureco.com
depureco@depureco.com
depureco@documentipec.com

C.F. e P.I. 02258610357
Registro Imprese di Torino - R.E.A. TO-1149668
Capitale Sociale: € 25.000 i.v.



DECLARATION OF CONFORMITY FOR ATEX VERSIONS

PUMA 10 DEX 1/2D - PUMA 15 DEX 1/2D - PUMA 20 DEX 1/2D -

PUMA 25 DEX 1/2D - PUMA 30 P DEX 1/2D - PUMA 30 S DEX 1/2D



DECLARATION OF COMPLIANCE

The manufacturer:

DEPURECO INDUSTRIAL VACUUMS S.r.l. – Via Venezia, 32 – 10088 Volpiano (TO) – ITALY |
Phone. +39 011 98 59 117 – Fax + 39 011 98 59 326 – Tax code. | VAT REG. NO.
02258610357

e-mail: depureco@depureco.com – www.depureco.com

hereby declares

under their sole responsibility that the vacuum cleaner model described in this manual



To which this declaration refers, complies with the essential safety requirements provided by the Machinery Directive 2006/42/EC, the Directive 2014/30/EU regarding Electromagnetic Compatibility, the Directive 2011/65/EU - ROHS - regarding restriction of the use of certain hazardous substances in electrical and electronic appliances and by the ATEX Directive 2014/34/EU with the following details.

The conformity has been verified in accordance with the requirements mentioned by the Standards:

UNI EN 1127-1

UNI EN ISO 80079-36

EN 60079-0:2018

EN60079-31:2014

Marking: 0474 II 1/2 D Ex htc IIIC T140°C Da/Dc

The Notified Body TÜV Nord issued the EU Type Certificate: TÜV CY 21 ATEX 0206460 X

The production control was carried out by Notified Body No. 0474 RINA Services S.p.a.

The Harmonised Standards applied for the design, manufacture and testing of the vacuum cleaner are listed in a technical file stored at the technical department of DEPURECO S.r.l. premises.

This declaration shall become invalid if modifications on the vacuum cleaner are carried out without approval from the manufacturer.

First issue: 15 June 2019

Revision 01: 16 October 2023.

The Legal Representative
Marco Devincentis CEO

Depureco Industrial Vacuums Srl
Società soggetta a direzione e coordinamento COFISE spa

PERFORMANCE ON VACUUM SINCE 1972

Via Venezia, 32 · 10088 Volpiano (TO)
Tel. +39 011 98.59.117
Fax +39 011 98.59.326

www.depureco.com
depureco@depureco.com
depureco@documentipecc.com

C.F. e P.I. 02258610357
Registro Imprese di Torino · R.E.A. TO-1149668
Capitale Sociale: € 25.000 i.v.





1. INFORMATION SECTION

IMPORTANT - The term and logo DEPURECO in this document refer to and are the property of DEPURECO INDUSTRIAL VACUUMS S.r.l.

This document is the exclusive property of DEPURECO S.r.l. Therefore, its reproduction by any means (graphic, computer, etc.), partial or total, is prohibited without the authorization of the Company Management.

1.1. PREFACE

Dear Customer

Thank you for choosing DEPURECO and congratulations on selecting a DEPURECO vacuum cleaner from the PUMA | PUMA ACD | PUMA DEX 1/3D | PUMA DEX 1/2D series.

We have prepared this manual to enable you to fully appreciate the quality of this machine.

We recommend reading it thoroughly before using the product for the first time.

It contains important information, tips and warnings for the use and maintenance of the vacuum cleaner that will help you take full advantage of the technical features of your machine.

It is recommended to read carefully the messages, warnings and directions, preceded by the symbols:



For the safety of people.



For the integrity of the aspirator.



For the preservation of the environment.

This manual describes the following models:

- PUMA 10
- PUMA 15 P
- PUMA 15 S
- PUMA 18 P
- PUMA 18 S
- PUMA 20
- PUMA 25
- PUMA 30 P
- PUMA 30 S
- PUMA 35 P
- PUMA 35 S
- PUMA 10 SP
- PUMA 15 P SP
- PUMA 15 S SP
- PUMA 18 P SP
- PUMA 18 S SP
- PUMA 20 SP
- PUMA 25 SP
- PUMA 30 P SP
- PUMA 30 S SP
- PUMA 35 P SP
- PUMA 35 S SP
- PUMA 10 ACD
- PUMA 15 P ACD
- PUMA 15 S ACD
- PUMA 18 P ACD
- PUMA 18 S ACD
- PUMA 20 ACD
- PUMA 25 ACD
- PUMA 30 P ACD
- PUMA 30 S ACD
- PUMA 35 P ACD
- PUMA 35 S ACD
- PUMA 10 DEX 1/3D
- PUMA 15 DEX 1/3D
- PUMA 20 DEX 1/3D
- PUMA 25 DEX 1/3D
- PUMA 30 P DEX 1/3D
- PUMA 30 S DEX 1/3D
- PUMA 10 SP DEX 1/3D
- PUMA 15 SP DEX 1/3D
- PUMA 20 SP DEX 1/3D
- PUMA 25 SP DEX 1/3D
- PUMA 10 DEX 1/2D
- PUMA 15 DEX 1/2D
- PUMA 20 DEX 1/2D
- PUMA 25 DEX 1/2D
- PUMA 30 P DEX 1/2D
- PUMA 30 S DEX 1/2D
- PUMA 10 SP DEX 1/2D
- PUMA 15 SP DEX 1/2D
- PUMA 20 SP DEX 1/2D
- PUMA 25 SP DEX 1/2D



Machines are classified according to their degree of dust filtration efficiency:

- L (light risk): in vacuum cleaners with a class L filter, the maximum degree of dust penetration is less than 1 percent (Degree of penetration < 1 %);
- M (medium risk): in vacuum cleaners with M filter, the maximum degree of dust particle penetration is less than 0.1 percent (Degree of penetration < 0.1 %);
- H (high hazard): in vacuum cleaners with filter H, the maximum degree of dust particle penetration is less than 0.005% (Degree of penetration < 0.005 %); This vacuum cleaner is designed to perform vacuuming, cleaning and collection operations of solid materials (dust and processing residues).

This specific model has undergone strict testing to ensure maximum reliability; its smooth operation and longevity will depend on good maintenance and careful use.

This manual is an integral part of the vacuum cleaner and must accompany it, until it is scrapped. In case of loss or damage, a replacement copy should be requested from DEPURECO INDUSTRIAL VACUUMS S.r.l. (hereafter referred to simply as DEPURECO).

The technical information contained in this manual is the property of DEPURECO and should be considered confidential in nature.

Reproduction, even in part, of the graphic design, text and illustrations is prohibited by law.

Some details depicted in the illustrations in this manual may differ from those in your vacuum cleaner, as some components may have been removed in order to ensure maximum clarity of the illustrations.

The topics covered in this manual, are those expressly required by the Machinery Directive 2006/42/EC and the technical data given are derived from the technical file stored at DEPURECO.


In compliance with Regulation 1907/2006/EC (REACH), DEPURECO declares that its products do not contain any of the substances, so-called substances of very high concern - SVHC i.e. Substances of Very High Concern - listed in the Candidate List.

This manual can be accessed via the QR code affixed to the vacuum cleaner or via the website www.depureco.com. Alternatively, contact the manufacturer Depureco. The manual should be made available to all personnel responsible for operating and maintaining the vacuum cleaner. For any dispute, the Court of Turin (Italy) shall have jurisdiction.


The QR code with the manual must accompany the vacuum cleaner in case of resale!



1.2. IDENTIFICATION OF MAJOR PARTS



- 1. Handle for handling the vacuum cleaner
- 2. Electrical cabinet
- 3. Lid
- 4. Filter chamber
- 5. Dust/debris collection container
- 6. Absolute filter kit (where applicable)
- 7. Suction nozzle
- 8. Fixed wheels
- 9. Pivoting wheels
- 10. Lever for unhooking and hooking the container
- 11. Engine bonnet
- 12. Base
- 13. Silencer
- 14. Pump
- 15. Box 4 pilots





1.3. OPTIONAL PARTS


Depending on the vacuum cleaner's application, a wide range of other optional accessories is available from DEPURECO.

1.4. MANUFACTURER IDENTIFICATION DATA

Depureco Industrial Vacuums S.r.l.
Via Venezia 32, 10088, Volpiano (TO), Italy
tel: +39 011 98 59 117 fax: +39 011 98 59 326 P.I. 02258610357
e-mail: depureco@depureco.com
website: www.depureco.com

1.5. NAME PLATE

Model	XXXX		Via Venezia, 32 10088 Volpiano Tel. +39 011 9859117 Fax +39 011 9859326
Serial No.	X2X - XXXX	Year	XX/202X
Max power	X,X kW - X,X A		
Max voltage	XXXV X ~ ac X0 Hz		
Dust class	X	Weight	XX Kg
		IP Protection	XX
T. ambient	-15 C° / + 40 C°		
www.depureco.com MADE IN ITALY			



1.6. INTENDED USES

PUMA 10 - PUMA 12 - PUMA 15 P - PUMA 15 S - PUMA 18 P - PUMA 18 S - PUMA 20 - PUMA 25 - PUMA 30 P - PUMA 30 S - PUMA 35 P - PUMA 35 S

These vacuum cleaners are manufactured according to Directive 2006/42/EC, are designed for use by a single operator, and are intended for:

- to industrial use, such as in manufacturing plants or warehouses;
- To dry/wet cleaning of floors or walls;
- To the suction of wet or damp substances;
- To the extraction of dry, non-combustible dust.

WARNING

Where there is the presence of combustible dust and/or flammable gases in the workplace, it is the responsibility of the Employer to make the classification of the area and choose a Category machine (as defined in Directive 2014/34/EU).

Any other use is considered **NON-COMPLIANT** with the intended use.

PUMA ACD

These vacuum cleaners are manufactured in accordance with Directive 2006/42/EC, are designed for use by a single operator, and are intended for:

- to industrial use, such as in manufacturing plants or warehouses;
- vacuuming dry, flammable, deposited, and hazardous dust (dust class according to EN 60335-2-69);
- Vacuum non-explosive dust;
- Vacuum flammable dusts of all explosion classes (except dusts with minimum ignition energy MIE < 3 mJ);
- flammable dust from a zone 22 if the equipment is installed outside potentially explosive areas.

The device **NOT** Is suitable for:

- Vacuum ignition sources and dust with a glow temperature ≤ 190 °C;



- Inhale explosive substances or equivalent, explosive vapor-air mixtures, as well as Mg dust;
- Vacuuming of flammable fluids (flammable, easily flammable, highly flammable according to the Dangerous Substances Directive 67/ 548/EEC) (flash point less than 55 °C), as well as mixtures of flammable powders with flammable fluids;
- Aspirate mixtures of flammable fluids and flammable dusts;
- Inhale glowing or hot particles to avoid causing a fire or explosion.
- Be connected to a machine that generates dust.

WARNING

Where there is the presence of combustible dust and/or flammable gases in the workplace, it is the responsibility of the Employer to make the classification of the area and choose a Category machine (as defined in Directive 2014/34/EU).

Any other use is considered **NON-COMPLIANT** with the intended use.

PUMA 10 DEX 1/3D - PUMA 15 DEX 1/3D - PUMA 20 DEX 1/3D - PUMA 25 DEX 1/3D - PUMA 30 DEX 1/3D

These vacuum cleaners are built according to Directive 2014/34/EU, are designed to be used by a single operator, and are intended for:

- to industrial use, such as in manufacturing plants or warehouses;
- To indoor and indoor use;
- To the extraction of combustible dust and/or dry particles in atmospheres classified as **Zone 22**;
- aspirated particles must have the following limitations:
Minimum ignition energy (MIE) of the powder > 3mJ.

WARNING

It is the responsibility of the Employer to make the zone classification and choose a Category machine (as defined in Directive 2014/34/EU)

Any other use is considered **NON-COMPLIANT** with the intended use.

PUMA 10 DEX 1/2D - PUMA 15 DEX 1/2D - PUMA 20 DEX 1/2D - PUMA 25 DEX 1/2D - PUMA 30 DEX 1/2D

These vacuum cleaners are built according to Directive 2014/34/EU, are designed to be used by a single operator, and are intended for:

- to industrial use, such as in manufacturing plants or warehouses;
- To indoor and indoor use;
- To the extraction of combustible dust and/or dry particles in atmospheres classified as **Zone 21 e Zone 22**;
- aspirated particles must have the following limitations:
Minimum ignition energy (MIE) of the powder > 3mJ.

WARNING

It is the responsibility of the Employer to make the zone classification and choose a Category machine (as defined in Directive 2014/34/EU)

Any other use is considered **NON-COMPLIANT** with the intended use.



PUMA 10 DEX 1/3D - PUMA 15 DEX 1/3D - PUMA 20 DEX 1/3D - PUMA 25 DEX 1/3D - PUMA 30 DEX 1/3D

These vacuum cleaners are built according to Directive 2014/34/EU, are designed to be used by a single operator, and are intended for:

- to industrial use, such as in manufacturing plants or warehouses;
- To indoor and indoor use;
- To the extraction of combustible dust and/or dry particles in atmospheres classified as **Zone 22**;
- aspirated particles must have the following limitations:
Minimum ignition energy (MIE) of the powder > 3mJ.

! WARNING

It is the responsibility of the Employer to make the zone classification and choose a Category machine (as defined in Directive 2014/34/EU)

Any other use is considered **NON-COMPLIANT** with the intended use.

PUMA 10 DEX 1/2D - PUMA 15 DEX 1/2D - PUMA 20 DEX 1/2D - PUMA 25 DEX 1/2D - PUMA 30 DEX 1/2D

These vacuum cleaners are built according to Directive 2014/34/EU, are designed to be used by a single operator, and are intended for:

- to industrial use, such as in manufacturing plants or warehouses;
- To indoor and indoor use;
- To the extraction of combustible dust and/or dry particles in atmospheres classified as **Zone 21 e Zone 22**;
- aspirated particles must have the following limitations:
Minimum ignition energy (MIE) of the powder > 3mJ.

! WARNING

It is the responsibility of the Employer to make the zone classification and choose a Category machine (as defined in Directive 2014/34/EU)

Any other use is considered **NON-COMPLIANT** with the intended use.

1.7. ATEX MARKING

PUMA 10 DEX 1/3D - PUMA 15 DEX 1/3D - PUMA 20 DEX 1/3D - PUMA 25 DEX 1/3D - PUMA 30 DEX 1/3D

CE  II 1/3 D Ex htc IIIC T140°C Da/Dc

PUMA 10 DEX 1/2D - PUMA 15 DEX 1/2D - PUMA 20 DEX 1/2D - PUMA 25 DEX 1/2D - PUMA 30 DEX 1/2D

CE  II 1/2 D Ex htc IIIC T140°C Da/Dc

1.8. ALLOWABLE ENVIRONMENTAL CONDITIONS

To ensure proper operation of the vacuum cleaner, it must be located away from the weather (rain, hail, snow, fog, suspended dust, etc.), with an ambient temperature between 5° and 45°C and humidity not exceeding 70%. The work environment should be clean and adequately bright.



1.9. NOISE LEVEL

Phonometric tests carried out on this specific vacuum cleaner model show a sound pressure level of:

Machine	Noise level
PUMA 10	74 dB(A)
PUMA 12	74 dB(A)
PUMA 15 P	74 dB(A)
PUMA 15 S	74 dB(A)
PUMA 18 P	74 dB(A)
PUMA 18 S	74 dB(A)
PUMA 20	74 dB(A)
PUMA 25	74 dB(A)
PUMA 30 P	78 dB(A)
PUMA 30 S	78 dB(A)
PUMA 35 P	78 dB(A)
PUMA 35 S	78 dB(A)
PUMA 10 SP	74 dB(A)
PUMA 15 P SP	74 dB(A)
PUMA 15 S SP	74 dB(A)
PUMA 18 P SP	74 dB(A)
PUMA 18 S SP	74 dB(A)
PUMA 20 SP	74 dB(A)
PUMA 25 SP	74 dB(A)
PUMA 30 P SP	78 dB(A)
PUMA 30 S SP	78 dB(A)
PUMA 35 P SP	78 dB(A)
PUMA 35 S SP	78 dB(A)
PUMA 10 ACD	74 dB(A)
PUMA 15 P ACD	74 dB(A)
PUMA 15 S ACD	74 dB(A)
PUMA 18 P ACD	74 dB(A)
PUMA 15 S ACD	74 dB(A)
PUMA 20 ACD	74 dB(A)
PUMA 25 ACD	74 dB(A)
PUMA 30 P ACD	78 dB(A)
PUMA 30 S ACD	78 dB(A)
PUMA 35 P ACD	78 dB(A)
PUMA 35 S ACD	78 dB(A)



Machine	Noise level
PUMA 10 DEX 1/3D	74 dB(A)
PUMA 15 DEX 1/3D	74 dB(A)
PUMA 20 DEX 1/3D	74 dB(A)
PUMA 25 DEX 1/3D	74 dB(A)
PUMA 30 P DEX 1/3D	78 dB(A)
PUMA 30 S DEX 1/3D	78 dB(A)
PUMA 10 SP DEX 1/3D	74 dB(A)
PUMA 15 SP DEX 1/3D	74 dB(A)
PUMA 20 SP DEX 1/3D	74 dB(A)
PUMA 25 SP DEX 1/3D	74 dB(A)
PUMA 10 DEX 1/2D	74 dB(A)
PUMA 15 DEX 1/2D	74 dB(A)
PUMA 20 DEX 1/2D	74 dB(A)
PUMA 25 DEX 1/2D	74 dB(A)
PUMA 30 P DEX 1/2D	78 dB(A)
PUMA 30 S DEX 1/2D	78 dB(A)
PUMA 10 SP DEX 1/2D	74 dB(A)
PUMA 15 SP DEX 1/2D	74 dB(A)
PUMA 20 SP DEX 1/2D	74 dB(A)
PUMA 25 SP DEX 1/2D	74 dB(A)

 **WARNING**

- For sound pressure levels above 85 dB(A), workers must be protected by appropriate personal protective equipment (PPE), such as approved individual hearing protectors.
- For such conditions, it is necessary to provide workers with training and information on the risks of noise exposure.



1.10. TECHNICAL DATA

	Unit of measurement	PUMA 10	PUMA 15 P	PUMA 15 S	PUMA 18 P	PUMA 18 S
Weight	[kg]	295	330	310	355	335
Dimensions	[mm]	850 x 1550	850 x 1550	850 x 1550	850 x 1550	850 x 1550
Height	[mm]	1980	1980	1980	1980	1980
Voltage / Frequency	[V] - [Hz]	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60
Power	[Watt] - [HP]	7500 - 10	11000 - 15	11000 - 15	12500 - 18	12500 - 18
Suction mouth diameter	[Ø mm]	100	100	100	100	100
Motors type		Side channel turbine	Side channel turbine	Side channel turbine	Side channel turbine	Side channel turbine
Continuous vacuum	[m Bar]	260	300	440	440	530
Max air flow rate	[m ³ /h]	730	950	550	1120	720
Primary filter		Stellar	Stellar	Stellar	Stellar	Stellar
Primary filter surface	[cm ²]	45000	45000	45000	45000	45000
Media		Polyester	Polyester	Polyester	Polyester	Polyester
Absolute filter		HEPA H14 *	HEPA H14 *	HEPA H14 *	HEPA H14 *	HEPA H14 *
Absolute filter surface	[cm ²]	110000	110000	110000	110000	110000
Noisiness	[dB(A)]	74	74	74	74	74
Container capacity	[L]	175	175	175	175	175

* = optional filter and/or cartridge



	Unit of measurement	PUMA 20	PUMA 25	PUMA 30 P	PUMA 30 S	PUMA 35 P	PUMA 35 S
Weight	[kg]	350	370	560	620	654	650
Dimensions	[mm]	850 x 1550	850 x 1550	1050 x 1950	1050 x 1950	1050 x 1950	1050 x 1950
Height	[mm]	1980	1980	2300	2300	2300	2300
Voltage / Frequency	[V] - [Hz]	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60
Power	[Watt] - [HP]	15000 - 20	18500 - 25	22000 - 30	20000 - 28	25000 - 34	25000 - 34
Suction mouth diameter	[Ø mm]	100	100	130	130	130	130
Motors type		Side channel turbine	Side channel turbine	Side channel turbine	Side channel turbine	Side channel turbine	Side channel turbine
Continuous vacuum	[m Bar]	350	320	275	460	220	445
Max air flow rate	[m ³ /h]	950	1380	1770	1100	2100	1130
Primary filter		Stellar	Stellar	Stellar	Stellar	Stellar	Stellar
Primary filter surface	[cm ²]	45000	45000	110000	110000	110000	110000
Media		Polyester	Polyester	Polyester	Polyester	Polyester	Polyester
Absolute filter		HEPA H14 *	HEPA H14 *	HEPA H14 *	HEPA H14 *	HEPA H14 *	HEPA H14 *
Absolute filter surface	[cm ²]	110000	110000	110000	110000	110000	110000
Noisiness	[dB(A)]	74	74	78	78	78	78
Container capacity	[L]	175	175	175	175	175	175

* = optional filter and/or cartridge



	Unit of measurement	PUMA 10 SP	PUMA 15 P SP	PUMA 15 S SP	PUMA 18 P SP	PUMA 18 S SP
Weight	[kg]	295	330	310	355	335
Dimensions	[mm]	850 x 1550	850 x 1550	850 x 1550	850 x 1550	850 x 1550
Height	[mm]	1980	1980	1980	1980	1980
Voltage / Frequency	[V] - [Hz]	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60
Power	[Watt] - [HP]	7500 - 10	11000 - 15	11000 - 15	12500 - 18	12500 - 18
Suction mouth diameter	[Ø mm]	100	100	100	100	100
Motors type		Side channel turbine	Side channel turbine	Side channel turbine	Side channel turbine	Side channel turbine
Continuous vacuum	[m Bar]	260	300	440	440	530
Max air flow rate	[m ³ /h]	730	950	550	1120	720
Primary filter (SP cartridge)		3x cartridge	3x cartridge	3x cartridge	3x cartridge	3x cartridge
Primary filter surface area (SP cartridges)	[cm ²]	120000	120000	120000	120000	120000
Media		Antistatic polyester	Antistatic polyester	Antistatic polyester	Antistatic polyester	Antistatic polyester
Absolute filter		HEPA H14 *	HEPA H14 *	HEPA H14 *	HEPA H14 *	HEPA H14 *
Absolute filter surface	[cm ²]	110000	110000	110000	110000	110000
Noisiness	[dB(A)]	74	74	74	74	74
Container capacity	[L]	175	175	175	175	175

* = optional filter and/or cartridge



	Unit of measurement	PUMA 20 SP	PUMA 25 SP	PUMA 30 P SP	PUMA 30 S SP	PUMA 35 P SP	PUMA 35 S SP
Weight	[kg]	350	370	560	620	654	650
Dimensions	[mm]	850 x 1550	850 x 1550	1050 x 1950	1050 x 1950	1050 x 1950	1050 x 1950
Height	[mm]	1980	1980	2300	2300	2300	2300
Voltage / Frequency	[V] - [Hz]	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60
Power	[Watt] - [HP]	15000 - 20	18500 - 25	22000 - 30	20000 - 28	25000 - 34	25000 - 34
Suction mouth diameter	[Ø mm]	100	100	130	130	130	130
Motors type		Side channel turbine	Side channel turbine	Side channel turbine	Side channel turbine	Side channel turbine	Side channel turbine
Continuous vacuum	[m Bar]	350	320	275	460	220	445
Max air flow rate	[m ³ /h]	950	1380	1770	1100	2100	1130
Primary filter (SP cartridge)		3x cartridge	3x cartridge	4x cartridge	4x cartridge	4x cartridge	4x cartridge
Primary filter surface (SP cartridges)	[cm ²]	120000	120000	180000	180000	180000	180000
Media		Antistatic polyester	Antistatic polyester	Antistatic polyester	Antistatic polyester	Antistatic polyester	Antistatic polyester
Absolute filter		HEPA H14 *	HEPA H14 *	HEPA H14 *	HEPA H14 *	HEPA H14 *	HEPA H14 *
Absolute filter surface	[cm ²]	110000	110000	110000	110000	110000	110000
Noisiness	[dB(A)]	74	74	78	78	78	78
Container capacity	[L]	175	175	175	175	175	175

* = optional filter and/or cartridge



	Unit of measurement	PUMA 10 ACD	PUMA 15 P ACD	PUMA 15 S ACD	PUMA 18 P ACD	PUMA 18 S ACD
Weight	[kg]	295	330	310	355	335
Dimensions	[mm]	850 x 1550	850 x 1550	850 x 1550	850 x 1550	850 x 1550
Height	[mm]	1980	1980	1980	1980	1980
Voltage / Frequency	[V] - [Hz]	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60
Power	[Watt] - [HP]	7500 - 10	11000 - 15	11000 - 15	12500 - 18	12500 - 18
Suction mouth diameter	[Ø mm]	100	100	100	100	100
Motors type		Side channel turbine	Side channel turbine	Side channel turbine	Side channel turbine	Side channel turbine
Continuous vacuum	[m Bar]	260	300	440	440	530
Max air flow rate	[m ³ /h]	730	950	550	1120	720
Primary filter		Stellar	Stellar	Stellar	Stellar	Stellar
Primary filter surface	[cm ²]	45000	45000	45000	45000	45000
Media		Antistatic polyester	Antistatic polyester	Antistatic polyester	Antistatic polyester	Antistatic polyester
Absolute filter		HEPA H14 *	HEPA H14 *	HEPA H14 *	HEPA H14 *	HEPA H14 *
Absolute filter surface	[cm ²]	45000	45000	45000	45000	45000
Noisiness	[dB(A)]	74	74	74	74	74
Container capacity	[L]	175	175	175	175	175

* = optional filter and/or cartridge



	Unit of measurement	PUMA 20 ACD	PUMA 25 ACD	PUMA 30 P ACD	PUMA 30 S ACD	PUMA 35 P ACD	PUMA 35 S ACD
Weight	[kg]	350	370	560	620	654	650
Dimensions	[mm]	850 x 1550	850 x 1550	1050 x 1950	1050 x 1950	1050 x 1950	1050 x 1950
Height	[mm]	1980	1980	2300	2300	2300	2300
Voltage / Frequency	[V] - [Hz]	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60
Power	[Watt] - [HP]	15000 - 20	18500 - 25	22000 - 30	20000 - 28	25000 - 34	25000 - 34
Suction mouth diameter	[Ø mm]	100	100	130	130	130	130
Motors type		Side channel turbine	Side channel turbine	Side channel turbine	Side channel turbine	Side channel turbine	Side channel turbine
Continuous vacuum	[m Bar]	350	320	275	460	220	445
Max air flow rate	[m ³ /h]	950	1380	1770	1100	2100	1130
Primary filter		Stellar	Stellar	Stellar	Stellar	Stellar	Stellar
Primary filter surface	[cm ²]	45000	45000	110000	110000	110000	110000
Media		Antistatic polyester	Antistatic polyester	Antistatic polyester	Antistatic polyester	Antistatic polyester	Antistatic polyester
Absolute filter		HEPA H14 *	HEPA H14 *	HEPA H14 *	HEPA H14 *	HEPA H14 *	HEPA H14 *
Absolute filter surface	[cm ²]	45000	45000	110000	110000	110000	110000
Noisiness	[dB(A)]	74	74	78	78	78	78
Container capacity	[L]	175	175	175	175	175	175

* = optional filter and/or cartridge



	Unit of measurement	PUMA 10 DEX 1/3D	PUMA 15 DEX 1/3D	PUMA 20 DEX 1/3D	PUMA 25 DEX 1/3D	PUMA 30 P DEX 1/3D	PUMA 30 S DEX 1/3D
Weight	[kg]	295	270	290	370	560	620
Dimensions	[mm]	850 x 1550	850 x 1550	850 x 1550	850 x 1550	1050 x 1950	1050 x 1950
Height	[mm]	1980	1980	1980	1980	2300	2300
Voltage / Frequency	[V] - [Hz]	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60
Power	[Watt] - [HP]	7500 - 10	11000 - 15	15000 - 20	18500 - 25	22000 - 30	18500 - 25
Suction mouth diameter	[Ø mm]	100	100	100	100	130	130
Motors type		ATEX side channel turbine	ATEX side channel turbine	ATEX side channel turbine	ATEX side channel turbine	ATEX side channel turbine	ATEX side channel turbine
Continuous vacuum	[m Bar]	280	300	350	270	240	550
Max air flow rate	[m ³ /h]	700	920	920	1350	1985	1180
Primary filter		Stellar	Stellar	Stellar	Stellar	Cartridge	Cartridge
Primary filter surface	[cm ²]	45000	45000	45000	45000	180000	180000
Media		Polyester ANTISTATIC	Polyester ANTISTATIC	Polyester ANTISTATIC	Polyester ANTISTATIC	Polyester ANTISTATIC	Polyester ANTISTATIC
Absolute filter		HEPA H14 *	HEPA H14 *	HEPA H14 *	HEPA H14 *	HEPA H14 *	HEPA H14 *
Absolute filter surface	[cm ²]	110000	110000	110000	110000	110000	110000
Noisiness	[dB(A)]	74	74	74	74	78	78
Container capacity	[L]	175	175	175	175	175	175

* = optional filter and/or cartridge



	Unit of measurement	PUMA 10 SP DEX 1/3D	PUMA 15 SP DEX 1/3D	PUMA 20 SP DEX 1/3D	PUMA 25 SP DEX 1/3D	PUMA 30 P DEX 1/3D	PUMA 30 S DEX 1/3D
Weight	[kg]	295	270	290	370	560	620
Dimensions	[mm]	850 x 1550	850 x 1550	850 x 1550	850 x 1550	1050 x 1950	1050 x 1950
Height	[mm]	1980	1980	1980	1980	2300	2300
Voltage / Frequency	[V] - [Hz]	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60
Power	[Watt] - [HP]	7500 - 10	11000 - 15	15000 - 20	18500 - 25	22000 - 30	18500 - 25
Suction mouth diameter	[Ø mm]	100	100	100	100	130	130
Motors type		ATEX side channel turbine	ATEX side channel turbine	ATEX side channel turbine	ATEX side channel turbine	ATEX side channel turbine	ATEX side channel turbine
Continuous vacuum	[m Bar]	280	300	350	270	240	550
Max air flow rate	[m ³ /h]	700	920	920	1350	1985	1180
Primary filter (SP cartridge)		3x cartridge	3x cartridge	3x cartridge	3x cartridge	4x cartridge	4x cartridge
Primary filter surface area (SP cartridges)	[cm ²]	120000	120000	120000	120000	180000	180000
Media		Polyester ANTISTATIC	Polyester ANTISTATIC	Polyester ANTISTATIC	Polyester ANTISTATIC	Polyester ANTISTATIC	Polyester ANTISTATIC
Absolute filter		HEPA H14 *	HEPA H14 *	HEPA H14 *	HEPA H14 *	HEPA H14 *	HEPA H14 *
Absolute filter surface	[cm ²]	110000	110000	110000	110000	110000	110000
Noisiness	[dB(A)]	74	74	74	74	78	78
Container capacity	[L]	175	175	175	175	175	175

* = optional filter and/or cartridge



	Unit of measurement	PUMA 10 DEX 1/2D	PUMA 15 DEX 1/2D	PUMA 20 DEX 1/2D	PUMA 25 DEX 1/2D	PUMA 30 P DEX 1/2D	PUMA 30 S DEX 1/2D
Weight	[kg]	295	270	290	370	560	620
Dimensions	[mm]	850 x 1550	850 x 1550	850 x 1550	850 x 1550	1050 x 1950	1050 x 1950
Height	[mm]	1980	1980	1980	1980	2300	2300
Voltage / Frequency	[V] - [Hz]	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60
Power	[Watt] - [HP]	7500 - 10	11000 - 15	15000 - 20	18500 - 25	22000 - 30	18500 - 25
Suction mouth diameter	[Ø mm]	100	100	100	100	130	130
Motors type		ATEX side channel turbine	ATEX side channel turbine	ATEX side channel turbine	ATEX side channel turbine	ATEX side channel turbine	ATEX side channel turbine
Continuous vacuum	[m Bar]	280	300	350	270	240	550
Max air flow rate	[m ³ /h]	700	920	920	1350	1985	1180
Primary filter		Stellar	Stellar	Stellar	Stellar	Cartridge	Cartridge
Primary filter surface	[cm ²]	45000	45000	45000	45000	180000	180000
Media		Polyester ANTISTATIC	Polyester ANTISTATIC	Polyester ANTISTATIC	Polyester ANTISTATIC	Polyester ANTISTATIC	Polyester ANTISTATIC
Absolute filter		HEPA H14 *	HEPA H14 *	HEPA H14 *	HEPA H14 *	HEPA H14 *	HEPA H14 *
Absolute filter surface	[cm ²]	110000	110000	110000	110000	110000	110000
Noisiness	[dB(A)]	74	74	74	74	78	78
Container capacity	[L]	175	175	175	175	175	175

* = optional filter and/or cartridge



	Unit of measurement	PUMA 10 SP DEX 1/2D	PUMA 15 SP DEX 1/2D	PUMA 20 SP DEX 1/3D	PUMA 25 SP DEX 1/2D	PUMA 30 P DEX 1/2D	PUMA 30 S DEX 1/2D
Weight	[kg]	295	270	290	370	560	620
Dimensions	[mm]	850 x 1550	850 x 1550	850 x 1550	850 x 1550	1050 x 1950	1050 x 1950
Height	[mm]	1980	1980	1980	1980	2300	2300
Voltage / Frequency	[V] - [Hz]	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60	400 - 50/60
Power	[Watt] - [HP]	7500 - 10	11000 - 15	15000 - 20	18500 - 25	22000 - 30	18500 - 25
Suction mouth diameter	[Ø mm]	100	100	100	100	130	130
Motors type		ATEX side channel turbine	ATEX side channel turbine	ATEX side channel turbine	ATEX side channel turbine	ATEX side channel turbine	ATEX side channel turbine
Continuous vacuum	[m Bar]	280	300	350	270	240	550
Max air flow rate	[m ³ /h]	700	920	920	1350	1985	1180
Primary filter (SP cartridge)		3x cartridge	3x cartridge	3x cartridge	3x cartridge	4x cartridge	4x cartridge
Primary filter surface area (SP cartridges)	[cm ²]	120000	120000	120000	120000	180000	180000
Media		Polyester ANTISTATIC	Polyester ANTISTATIC	Polyester ANTISTATIC	Polyester ANTISTATIC	Polyester ANTISTATIC	Polyester ANTISTATIC
Absolute filter		HEPA H14	HEPA H14	HEPA H14	HEPA H14	HEPA H14	HEPA H14
Absolute filter surface	[cm ²]	110000	110000	110000	110000	110000	110000
Noisiness	[dB(A)]	74	74	74	74	78	78
Container capacity	[L]	175	175	175	175	175	175



The vacuum cleaner can be equipped with the following filters, distinguished between the supplied and optional filters:

	STELLAR M	STELLAR ANTISTATIC M	STELLAR TEFLON	STELLAR NOMEX	STELLAR PTFE	STELLAR PTFE ANTISTATIC	CARTRIDGE CYLINDRICAL ANTISTATIC M	CARTRIDGE CONICA HEPA H13	CARTRIDGE HEPA H14
PUMA 10	●	○	○	○	○	○	-	-	○
PUMA 15 P	●	○	○	○	○	○	-	-	○
PUMA 15 S	●	○	○	○	○	○	-	-	○
PUMA 18 P	●	○	○	○	○	○	-	-	○
PUMA 18 S	●	○	○	○	○	○	-	-	○
PUMA 20	●	○	○	○	○	○	-	-	○
PUMA 25	●	○	○	○	○	○	-	-	○
PUMA 30 P	●	○	○	○	○	-	-	-	○
PUMA 30 S	●	○	○	○	○	-	-	-	○
PUMA 35 P	●	○	○	○	○	-	-	-	○
PUMA 35 S	●	○	○	○	○	-	-	-	○
PUMA 10 SP	-	-	-	-	-	-	●	-	○
PUMA 15 P SP	-	-	-	-	-	-	●	-	○
PUMA 15 S SP	-	-	-	-	-	-	●	-	○
PUMA 18 P SP	-	-	-	-	-	-	●	-	○
PUMA 18 S SP	-	-	-	-	-	-	●	-	○
PUMA 20 SP	-	-	-	-	-	-	●	-	○
PUMA 25 SP	-	-	-	-	-	-	●	-	○
PUMA 30 P SP	-	-	-	-	-	-	●	-	○
PUMA 30 S SP	-	-	-	-	-	-	●	-	○
PUMA 35 P SP	-	-	-	-	-	-	●	-	○
PUMA 35 S SP	-	-	-	-	-	-	●	-	○
PUMA 10 ACD	-	●	-	-	-	○	-	-	○
PUMA 15 P ACD	-	●	-	-	-	○	-	-	○
PUMA 15 S ACD	-	●	-	-	-	○	-	-	○
PUMA 18 P ACD	-	●	-	-	-	○	-	-	○
PUMA 18 S ACD	-	●	-	-	-	○	-	-	○
PUMA 20 ACD	-	●	-	-	-	○	-	-	○
PUMA 25 ACD	-	●	-	-	-	○	-	-	○
PUMA 30 P ACD	-	●	-	-	-	○	-	-	○
PUMA 30 S ACD	-	●	-	-	-	○	-	-	○
PUMA 35 P ACD	-	●	-	-	-	○	-	-	○
PUMA 35 S ACD	-	●	-	-	-	○	-	-	○

● = filter supplied with the vacuum cleaner
○ = optional filter



	STELLAR M	STELLAR ANTISTATIC M	STELLAR TEFLON	STELLAR NOMEX	STELLAR PTFE	STELLAR PTFE ANTISTATIC	CARTRIDGE CYLINDRICAL ANTISTATIC M	CARTRIDGE CONICA HEPA H13	CARTRIDGE HEPA H14
PUMA 10 DEX 1/3D	-	●	-	-	-	○	-	-	○
PUMA 15 DEX 1/3D	-	●	-	-	-	○	-	-	○
PUMA 20 DEX 1/3D	-	●	-	-	-	○	-	-	○
PUMA 25 DEX 1/3D	-	●	-	-	-	○	-	-	○
PUMA 30 P DEX 1/3D	-	●	-	-	-	-	-	-	○
PUMA 30 S DEX 1/3D	-	●	-	-	-	-	-	-	○
PUMA 10 SP DEX 1/3D	-	-	-	-	-	-	●	-	○
PUMA 15 SP DEX 1/3D	-	-	-	-	-	-	●	-	○
PUMA 20 SP DEX 1/3D	-	-	-	-	-	-	●	-	○
PUMA 25 SP DEX 1/3D	-	-	-	-	-	-	●	-	○
PUMA 10 DEX 1/2D	-	●	-	-	-	○	-	-	●
PUMA 15 DEX 1/2D	-	●	-	-	-	○	-	-	●
PUMA 20 DEX 1/2D	-	●	-	-	-	○	-	-	●
PUMA 25 DEX 1/2D	-	●	-	-	-	○	-	-	●
PUMA 30 P DEX 1/2D	-	●	-	-	-	-	-	-	●
PUMA 30 S DEX 1/2D	-	●	-	-	-	-	-	-	●
PUMA 10 SP DEX 1/2D	-	-	-	-	-	-	●	-	●
PUMA 15 SP DEX 1/2D	-	-	-	-	-	-	●	-	●
PUMA 20 SP DEX 1/2D	-	-	-	-	-	-	●	-	●
PUMA 25 SP DEX 1/2D	-	-	-	-	-	-	●	-	●

● = filter supplied with the vacuum cleaner

○ = optional filter

1.11. WARRANTY

DEPURECO guarantees this model of vacuum cleaner for a period of 12 months from the date of purchase, indicated on the fiscal document at the time of delivery of the product. The warranty shall be void if the vacuum cleaner has been repaired by unauthorized third parties or if equipment, accessories or components not supplied or authorized by DEPURECO or for which the serial number is found to have been removed (during the warranty period) are used. DEPURECO agrees to repair or replace free of charge those parts or components that within the warranty period are proven to be defective from manufacture.

Repairs are carried out exclusively at our premises or at the Service Center indicated by us and must be received carriage paid (freight charges to be paid by the user, unless otherwise agreed).

The warranty does not cover the cleaning of working organs.

The purchase tax document must be shown to the authorized technical personnel performing the repair or must accompany the vacuum cleaner in shipment. Defects not clearly attributed to material or manufacture will be investigated exclusively at our office or at our designated Technical Service Center. Should the claim prove to be unjustified, all costs of repair and/or replacement of parts, will be charged to the purchaser.

Excluded from the warranty are: accidental damage due to transportation, carelessness or inadequate handling, improper use, not in accordance with the warnings in this booklet, or arising from phenomena not dependent on normal use/operation of the vacuum cleaner.

DEPURECO is not liable for any personal injury or property damage resulting from improper or incorrect use of the vacuum cleaner.

For any dispute, the Court of Turin (Italy) shall have jurisdiction.



2. SAFETY SECTION

2.1. SAFETY INFORMATION

Pursuant to Legislative Decree 81/08 and subsequent additions and amendments, the Head of the Safety has an obligation to train, inform and educate workers on the hazards involved in vacuum cleaner use so that they are able to protect their own and others' safety.

Failure to observe basic safety regulations or precautions, could result in an accident during the use, maintenance and repair of the vacuum cleaner. An accident can often be avoided by recognizing potential dangerous situations before they occur. Proper training is the basic prerequisite for this.

WARNING

Use only original Depureco spare parts. We disclaim any responsibility for the use of non-original spare parts.

2.2. SAFETY PRESCRIPTIONS

WARNING

The directions below play an important role in completely preserving you from all the hazards you may encounter when operating the vacuum cleaner.

However, they will not be able to be separated from the competence and common sense of those who work, as an overall framework for careful accident prevention.

Additional safety requirements specific to different operations are listed in each section.

Prior to use, operators should receive the necessary training in the use of the machine and information on the substances for which it is to be used, including safe methods for removal and disposal of collected material.

Commissioning - connection to the power grid:

- Before commissioning, make sure the vacuum cleaner has no obvious damage.
- Before connecting the inlet, make sure the air hoses are properly positioned (for vacuum cleaners equipped with counter-current air cleaning system). Carry out the operation in a safe area free of explosive atmospheres.
- Before connecting the vacuum cleaner to the mains, make sure that the voltage indicated on the nameplate matches the mains voltage.
- Plug the power cord into an outlet with properly installed grounding contact/connection. Make sure the vacuum cleaner is turned off.
- Mains cable plugs and connectors must be protected from water splashes.
- Check for proper connection to the power grid.
- Ensure that the grounding clamp is properly connected, to a point for which continuity with the grounding system is guaranteed.
- Use only vacuum cleaners with mains connection cables in perfect condition in order to avoid the danger of electric shock.
- Regularly check for damage and signs of wear, cracking, or aging of the grid connection cable.

During operation, avoid:

- Step on, crush, pull or damage the power connection cable.
- Disconnect the cable from the mains only by pulling the plug (do not pull the cable itself).
- When replacing the power supply cable, replace it with one of the same type as the original one installed.
- The power cord must be replaced by the manufacturer's Service Department or equivalent qualified personnel.



It is absolutely forbidden:

- Use of this vacuum cleaner by persons who are not adults and properly trained.
- Make the electrical connection to a network without an efficient grounding.
- Outdoor use in the presence of atmospheric precipitation.
- The use and storage of the vacuum cleaner outdoors in humid conditions.
- The use of the vacuum cleaner in the absence of the appropriate lock placed on the rotating wheel during vacuuming operations.
- The use of the vacuum cleaner placed on unlevel and non-horizontal surfaces.
- Use in corrosive environments.
- Roll or bend the hose during suction.
- For ATEX versions and models, the use of hoses that are not antistatic in the mass (only surface antistaticity is not allowed).
- The use of original DEPURECO accessories is recommended. Check with an ohmmeter for electrical continuity:
 - between nozzle and end of suction accessories: the resistance detected must be less than $100M\Omega$ (for ATEX versions and models);
 - between container and plug (ground pin) in the case of electric machine, or between container and grounding wire (supplied) in the case of compressed air models: the resistance detected must be: - less than $10\ \Omega$ (for models and versions where compressed air supply is provided).
- Use of the machine in unclassified working environments according to the information on the machine's nameplate.
- Vacuum the following materials:
 - burning materials (embers, hot ashes, lit cigarettes, etc.);
 - open flames;
 - combustible gases;
 - Flammable, combustible, aggressive liquids (gasoline, solvents, acids, alkaline solutions, etc.);
 - Explosive and spontaneously igniting dusts/substances and/or mixtures thereof (magnesium powders, etc.).
- Prolonged contact with solvents and inhalation of their vapors.
- Use near open flames or heat sources; then ensure adequate ventilation.
- The use of the exhaust fan in rooms where the suitable air exchange rate is not guaranteed, in the case where exhaust air is recirculated in the said room. To meet the required limit values, the recirculation volume flow rate must not exceed 50% of the volume of fresh air.
- Tamper with or change the limiting valve set by the manufacturer (in models where present).
- Do not use the JetClean cleaning system in the presence of potentially explosive clouds in the atmosphere (for models and versions where this cleaning system is provided).
- Perform maintenance on the industrial vacuum cleaner in ATEX classified areas (for ATEX models and versions).
- Perform maintenance on the vacuum cleaner without first turning off the machine and unplugging the electrical plug from the outlet.
- Keep foreign materials such as debris, oil, tools and other objects inside the container that could damage operation and cause personal injury.
- The use of flammable or toxic solvents such as gasoline, benzene, ether and alcohol for cleaning.
- Use without the filter unit provided by the manufacturer.
- The use of the industrial vacuum cleaner in the absence of safety devices or with such devices inefficient
- The use of the industrial vacuum cleaner with guards and guards not in place.
- Insert hands inside the container positioning guides and between the container and the vacuum cleaner during the operation of Inserting and locking the debris container under the vacuum cleaner itself: movement of the lifting handle can cause fingers to be crushed. Therefore wear gloves when removing the suction head, filter unit or collection container.
- Open the container with the vacuum cleaner running.
- Open the container in the area classified as potentially explosive.
- Continue to keep the vacuum cleaner activated and powered through the mains plug in case of prolonged work breaks after use.



- Add extension lines, plug-in connection devices and adapters.
- Get on the vacuum cleaner.
- Move the vacuum cleaner while it is running.
- Wear loose or dangling garments such as ties, scarves, torn clothing that can snag or be sucked up by the vacuum cleaner.
- Touch electrical wires, switches, buttons, etc. with wet hands.
- Touching, while using the industrial vacuum cleaner, some components (motor terminal board, motor body in particular) that may reach high temperatures.

WARNING

This vacuum cleaner may contain dust that is harmful to health.

Emptying and maintenance procedures, including the removal of containers of dust collection should be carried out only by trained personnel wearing appropriate protective equipment.

This manual should always be available for reference on the planned operating cycle and whenever there is any doubt.

If it is lost or damaged, a replacement copy should be requested from DEPURECO.

PUMA ACD

- Observe the safety regulations applicable to the materials to be processed.
- Do not operate the device without the complete filter system.
- Simultaneous collection of several combustible dusts in the collection container may lead to fire or explosion.



2.3. ATEX SAFETY INSTRUCTIONS



- Hexagon Ex - ATEX Directive 2014/34/EU. In this manual, the Ex hexagon is placed alongside the main safety instructions on explosion risk.
- All personnel involved in installation, operation and maintenance of the equipment and its components should receive technical training corresponding to the tasks to be performed, particularly for working in areas with a potentially explosive atmosphere. Any changes made to this equipment may invalidate its safety requirements. Always follow the manufacturer's instructions.
- ZONE 20: An area where an explosive atmosphere in the form of a combustible dust cloud in the air is present permanently or for long periods or often.
- ZONE 21: An area where an explosive atmosphere in the form of a combustible dust cloud in the air is likely to form occasionally during normal activities.
- ZONE 22: An area where during normal activities an explosive atmosphere in the form of a combustible dust cloud is not likely to form and, if it does occur, is only of short duration. It is prohibited to use the apparatus where there are areas classified for the presence of gas as ZONE 0, 1 or 2
- Combustible powders with the following characteristics can be processed:

Self flammability in MIT cloud	°C	>215
Self-flammability in LIT layer	°C	>215
Minimum Trigger Energy (MIE) at all operating temperatures	°C	≥3

- It turns out that it is prohibited to use the device with hybrid mixtures, explosives and class St2 and St3 chemically unstable dusts.
- Depureco ATEX vacuum cleaners having II 1/3 D Ex htc IIIC T140°C Da/Dc marking are certified to be able to contain a ZONE 20 inside and can be used in ZONE 22.
- Depureco ATEX vacuum cleaners having II 1/2 D Ex h tb IIIC T140°C Da/Db marking are certified to be able to contain a ZONE 20 inside and can be used in ZONE 21 and ZONE 22.
- It is prohibited to use the device where areas classified as ZONE 0, 1 or 2 are present.
- It is the responsibility of the user to ensure that the equipment is used in a manner consistent with its intended use, particularly that it is used in ZONES classified as compatible with those for which the equipment is declared suitable by the manufacturer.
- The 'device is designed to work under standard environmental conditions:
 - Temperature $-15^{\circ}\text{C} \leq T_{\text{amb}} \leq +40^{\circ}\text{C}$.
 - Atmospheric pressure $+0.8/1.1$ bar.The treated product should have a temperature not exceeding 40°C .
- Any electrical or mechanical components to be installed on the equipment must be certified of a category suitable for use:
 - 3D category (ZONE 22).
 - 2D category (ZONE 21).
 - 1D category (ZONE 20).
- For maintenance or cleaning operations, the user should ensure that the equipment used (vacuum cleaners, portable lamps, etc.) is of a category suitable for the environment:
 - 3D category (ZONE 22).
 - 2D category (ZONE 21).
 - 1D category (ZONE 20).
- A periodic check of the equipotentiality condition, especially after maintenance operations, between the different metal parts of the equipment, especially the moving parts and filter cages, must be carried out.
- Strictly use antistatic/dissipative components that ensure electrical continuity.
- Before installation and start-up, provide visual inspection for possible transport damage. Instruments used for installation must comply with EN 1127-1 in relation to the area of use. As a preliminary operation carry out grounding and verification of its proper operation. Grounding is provided with visual indication by symbol in European Standard. In Start-up phases carry out the following checks:
 - Verify the proper grounding of the equipment and the condition of equipotentiality between the



- various parts of the equipment, especially the moving parts;
- Carry out blank test with acoustic verification (abnormal noise): in case of problems stop the equipment and check the assembly of moving parts;
 - electrical wiring must be carried out by qualified personnel and according to the wiring diagram.
- Adequate training of the operator who performs installation, start-up and normal operation maneuvers of the equipment must be done during the testing and delivery of the equipment.
 - The user must ensure that the plant within which the equipment will be installed has been adequately secured, from an explosion risk point of view, before it is started up, and also that the "Explosion Protection Document" has been prepared as required by the ATEX Directive 2014/34/EU.
 - THE INTRODUCTION (ASPIRATION) OF SOURCES OF INJECTION FROM OUTSIDE, including those due to self-ignition of dust or by embers combustion, IS PROHIBITED.
 - In the case of extraction of dusts that may give rise to self-ignition phenomena, the collection bin must be emptied immediately after each activity. This precaution should also be taken in the case of aspiration of dust of different types whose mixture may give rise to exothermic reactions.
 - A periodic check of the equipotentiality condition, especially after maintenance operations, between the different metal parts of the equipment, especially the moving parts and the handle baskets, must be carried out.
 - Installation, assembly and disassembly operations must be carried out on machinery that is switched off and in the absence of a potentially explosive atmosphere.
 - The installer must check that the process specifications correspond to the equipment characteristics on the nameplate (e.g., with reference to the maximum surface temperature). In the case of material with incompatible product characteristics, use of the equipment is prohibited.
 - Manuals for the ATEX components mounted on the equipment are provided in the appendix: the user must observe all safety instructions regarding the use of these components.
 - Cleaning of equipment to prevent the formation of combustible dust layers must be carried out by the user. Do not use compressed air for cleaning from dust layers, but appropriate vacuum systems suitable for handling potentially explosive dust (ATEX-certified vacuum cleaners).
 - A specially trained operator must be present at all times during the operation of the equipment and must take immediate action by stopping the equipment using the emergency button in case of malfunctions, e.g., abnormal noise (rupture of components), clogging of the inlet and vent piping, rupture of the filter sleeves, suction of foreign bodies presence or sources of ignition.
 - When installing and maintaining electrical parts (e.g., cables, cable glands and terminals) always follow the instructions in EN 60079-14. When opening junction boxes (for inspections), check that the gaskets are correctly present when closing them again.
 - The plug is not an ATEX type (or is not supplied): the user must connect the plug to an outlet located in a SAFE PLACE, or must arrange to install an ATEX plug.
 - Hoses, suction nozzles and filter sleeves are of the antistatic type declared by their respective manufacturers. It is forbidden to use other types of components.
 - Protection against atmospheric discharge must be present in the establishment where the equipment is used.
 - No ignition sources should be present in the immediate vicinity of the device, for example:
 - flames;
 - embers;
 - hot surfaces;
 - sparks (e.g., caused by metal cutting);
 - Stray currents and cathodic protection systems;
 - Electrical or mechanical equipment that is not ATEX certified;
 - electrostatic charges carried by operators or mobile equipment;
 - Radio frequency (RF) and electromagnetic waves (from 10^4Hz at $3 \times 10^{11}\text{Hz}$);
 - electromagnetic waves (from $3 \times 10^{11}\text{Hz}$ at $3 \times 10^{15}\text{Hz}$);
 - ionizing radiation;
 - ultrasound.



2.4. SAFETY PLATES AND SYMBOLS

Labels with safety symbols and/or messages are attached to the vacuum cleaner and packaging. At these pages their exact location and nature of the hazard is indicated.

WARNING

The nameplates and symbols below are indicative and may not be applicable to the models in the vacuum cleaner series described. The presence of each symbol will vary according to the specifications of the series and/or individual model.

WARNING

Ensure that all safety messages are legible. The user is required to immediately replace any safety plates that become illegible due to wear and tear or damage.

Clean them using a cloth, soap and water. Do not use solvents, naphtha or gasoline. Replace damaged plates by requesting them from DEPURECO.

If a nameplate is on a part that is being replaced, make sure a new nameplate is attached to the new part.



This sticker indicates that the device can vacuum dust up to class M.




This sticker indicates that the device can vacuum dust up to class H.



This sticker indicates the manual filter cleaning system.



This sticker warns of the danger of crushing limbs.




This sticker indicates the need to align the vacuum cleaner components for proper operation.



This sticker indicates that the vacuum cleaner is grounded.



This sticker indicates the supply voltage of the vacuum cleaner.



This sticker indicates the supply voltage of the vacuum cleaner.



This sticker indicates the maximum liquid level inside the container (for models and versions where applicable).



Hexagon Ex - ATEX Directive 2014/34/EU
This sticker indicates that the vacuum cleaner is certified for use in hazardous areas (for dedicated models and versions).



This sticker indicates that the device can vacuum combustible dust in areas not classified as Atex (for dedicated models and versions).



ATTENZIONE!
IN CASO DI MANCATO
AVVIO, VERIFICARE
CHE LE FASI NON
SIANO INVERTITE.

This sticker is applied to all Atex machines with direct start electrical panels (for dedicated models and versions).



This sticker indicates safety requirements.

WARNING

Read the operation and maintenance manual carefully before using the vacuum cleaner or performing maintenance work.

It is strictly forbidden to remove the safety labels on the vacuum cleaner and/or its components and packaging.

DEPURECO accepts no responsibility for the safety of the vacuum cleaner if this prohibition is not observed.



2.5. RESIDUAL RISKS

DEPURECO recommends strict adherence to the instructions, procedures and recommendations in this manual and to current safety regulations. In addition, DEPURECO recommends the use of the prescribed protective equipment, either integrated into the vacuum cleaner or individual.

In this view, the residual hazards analyzed that are present on the vacuum cleaner and/or its components may be:

Electrical hazards in maintenance due to the need to work under voltage

Pursuant to Legislative Decree 81/08-Articles 80 to 87-it is forbidden to work under voltage, except for the exceptions stipulated in that decree.

Risk of misuse in the presence of liquid, deflagrating and flammable substances

The vacuum cleaner should not be used in an environment containing liquid substances or in the form of liquids that can vaporize at room temperature, flammable dusts, gases.

Risks of operating in a humid environment

Comply with the limits given in this manual in Section 1.8 "Allowable Environmental Conditions."

Risk of misinterpretation of safety pictograms

With reference to the analysis of risks and their identification, DEPURECO has installed hazard labels from the regulations on graphic symbols on the vacuum cleaner.

The user is required to immediately replace safety plates that become illegible due to wear and tear or damage.

2.6. DIRECTIVES APPLIED

The following guidelines apply to the vacuum cleaner described in this manual:

- 2006/42/EC - Machinery Directive.
- 2014/30/EU - Electromagnetic compatibility directive.
- 2011/65/EU - ROHS - Directive on the restriction of the use of certain hazardous substances in electrical and electronic equipment.
- 2014/35/EU - Low Voltage Directive.
- 2014/34/EU - ATEX Directive (for ATEX models and versions).

The following standards or regulatory documents apply to the vacuum cleaner described in this manual:

- UNI EN 1127-1:2019 (for ATEX models and versions).
- UNI EN ISO 80079-36:2016 (for ATEX models and versions).
- UNI EN ISO 80079-37:2016 (for ATEX models and versions).
- EN 60079-0:2018 (for ATEX models and versions).
- EN 60335-1 (for ACD models and versions).
- EN IEC 61000-3-2:2019 (for ACD models and versions).
- EN IEC 63000:2018 (for ACD models and versions).
- IEC 60335-2-69 (for ACD models and versions).
- EN 55014-2:2015 (for ACD models and versions).

Regulatory references, including mandatory requirements, are managed in the Quality Management System and archived at DEPURECO.




3. HANDLING, UNPACKING AND INSTALLATION SECTION

3.1. HANDLING

The instructions that follow also indicate the steps to be taken in case the vacuum cleaner should be newly packed or unpacked for later transport.

Packaging size:



	MU.	A	B	H
PUMA 10 - PUMA 15 P - PUMA 15 S - PUMA 18 P - PUMA 18 S - PUMA 20 - PUMA 25 - PUMA 10 ACD - PUMA 15 P ACD - PUMA 15 S ACD - PUMA 18 P ACD - PUMA 18 S ACD - PUMA 20 ACD - PUMA 25 ACD	[cm]	170	90	225
PUMA 30 P - PUMA 30 S - PUMA 35 P - PUMA 35S - PUMA 30 P ACD - PUMA 30 S ACD - PUMA 35 P ACD - PUMA 35 S ACD	[cm]	190	100	250
PUMA 10 DEX 1/3D - PUMA 15 DEX 1/3D - PUMA 20 DEX 1/3D - PUMA 25 DEX 1/3D	[cm]	170	90	225
PUMA 30 P DEX 1/3D - PUMA 30 S DEX 1/3D	[cm]	190	100	250
PUMA 10 DEX 1/2D - PUMA 15 DEX 1/2D - PUMA 20 DEX 1/2D - PUMA 25 DEX 1/2D	[cm]	170	90	225
PUMA 30 P DEX 1/2D - PUMA 30 S DEX 1/2D	[cm]	190	100	250

Lifting and subsequent handling of the vacuum cleaner should be done only by a forklift of appropriate capacity for the weight.

When moving with the forklift, lift the load 200 mm off the ground and swing backward.

When lifting loads, take into account the height of the environment in which you are working.

Before starting the movement make sure the passage area is clear and that there are no moving objects on the package. For lifting and handling, apply current accident prevention laws and normal forklift driving instructions.


Move the device only at walking pace and, on sloping paths, in twos if necessary.




3.2. UNPACKING

To perform unpacking of the machine:

- Cut the fixing tapes.




- Remove the retainers with the help of a hammer and screwdriver.



- Unwrap the cardboard packaging.



- Remove all fasteners provided by the manufacturer at packing stage using appropriate tools.



Remove the machine from the support platform by helping yourself with a ramp of suitable capacity and leading the vacuum from the handle.

Conduct these operations on flat, horizontal surfaces. The load-bearing capacity of the support surface must be adequate for the weight of the machine.

Provide ample space around the plant in order to operate with freedom of movement and to allow easy operations by operators in anticipation of future maintenance work.

WARNING

Depureco is not liable for any damage caused to the machine during lifting if the proper equipment is not used.

WARNING

For possible subsequent transport, the vacuum cleaner should be anchored to the support platform by means of a locking system similar to that described above.

WARNING

Dispose of packaging materials in accordance with current legislation.



3.3. INSTALLATION

! WARNING!


The following must be complied with before installing the vacuum cleaner
In section 2.2 "Safety requirements."

! WARNING!

Before installing the vacuum cleaner, it is necessary to make a careful prior visual inspection in order to detect any damage incurred during transportation.

If one or more components are found to be damaged, it is essential not to proceed further with the installation and to report the anomaly found to Depureco, agreeing with it on the action to be taken.
The machine arrives with the planned filter unit already installed.

- Insert the flexible hose with the terminal into the appropriate suction inlet (Part 7, Section 1.2).
- Insert the desired accessory for the suction type from the opposite side of the hose.




Note: The hose with its terminals and suction accessories are not included in the STANDARD equipment. Contact your dealer (or DEPURECO) for information regarding the different types of OPTIONAL accessories that can be used for this specific vacuum cleaner model.

! WARNING

The following operation should be carried out by an electrical technician.

Verify that the electrical supply line matches the voltage and frequency indicated on the vacuum cleaner nameplate and that it is efficiently grounded.



- Finally, insert the plug (standard equipment) into the power outlet.



⚠ WARNING

The power outlet to power the vacuum cleaner must be protected by a CE-compliant mains disconnect switch.

⚠ WARNING


Do not insert the plug into the outlet with wet hands. The use of extension cords is not allowed. Before attaching the vacuum cleaner to the power outlet, make sure:

- The power cord is intact and in perfect condition.
- The voltage of the supply line corresponds to that marked on the nameplate data label of the vacuum cleaner.
- The power plug is properly inserted into the power outlet.
- The hose is properly inserted and locked into the suction nozzle.
- The debris container/Endless Bag is regularly present and locked on the vacuum cleaner.
- No dust escapes when replacing accessories.

Before turning on the vacuum cleaner again, make sure the pump has stopped completely.

Pneumatic power connection (for versions and models where provided)

- Ensure that the air tubes are correctly fitted to the pilot box (Part 15, Section 1.2).
- Connect the air tubes coming out of the shoulder and the filter regulator to the fittings on the cover (Part 3, Section 1.2).
- Make sure the air hoses are properly connected to the filter regulator (O). The required air supply is max. 6 bar.
- Connect the air tubes to the four valves (four $\varnothing 6$ mm tubes) located above the cartridges and to the tank (one $\varnothing 8$ mm tube) (P).
- To ensure proper operation, the air fed into the vacuum cleaner, must be dehumidified.






4. OPERATION SECTION

4.1. COMMAND DESCRIPTION

WARNING

- Before proceeding to use the vacuum cleaner, it is necessary to comply with what is stated in Section 2.2 "Safety Requirements."
- Only authorized personnel who have read these operating and maintenance instructions are allowed to use the vacuum cleaner. The user of the equipment and the maintenance technician who carry out permissible work on the vacuum cleaner must receive appropriate education, information and training, as required by current labor safety laws, and use for the various operations, the prescribed personal protective equipment (PPE), such as safety footwear, gloves, goggles, mask, etc. The user must observe the current regulations for sucked materials and their disposal.
- Before a new work cycle, the personnel in charge must verify that the normal safe operating conditions of the vacuum cleaner and, in particular, the safety devices and protective guards involved in the operation are ensured.
- In case of prolonged work breaks and after use is over, turn off the appliance from the appliance switch and unplug the mains plug.



- 1. disconnecter I/O
- Emergency mushroom 2
- White light: voltage presence 3
- Yellow light: thermal shot 4
- Green light: vacuum cleaner start 5
- Green button: start vacuum cleaner 6
- Red button: vacuum cleaner stop 7



4.2. DUTY CYCLE

Before starting the aspiration, it is necessary to comply with what is stated in Section 2.2 "Safety Requirements." Specifically:

- Make sure the power cord is not damaged and is in perfect condition.
- Before plugging in the power outlet, make sure that the voltage of the power line matches that indicated on the nameplate data label of the appliance.
- Make sure the power plug is properly inserted into the power outlet.
- Ensure that the suction arm or hose is properly inserted and locked into the suction nozzle.
- Ensure that the debris collection container (if any) is properly positioned and locked under the vacuum cleaner chamber.
- Ensure that the Endless Bag collection system (where fitted) is properly positioned and locked under the vacuum cleaner chamber and that the bag segment is ready for use.

ATTENTION!


To move the vacuum cleaner, use the handles provided (Part 1, Section 1.2).

WARNING


Do not move the vacuum cleaner while it is in operation.

To start suction, proceed as follows:

- Lock the vacuum cleaner by means of the lever on the turning wheel, as shown in the figure.




- Grip the end of the hose with the chosen suction attachment or place the end of the suction arm at the suction point.
- Rotate the disconnecter from **O** a **I** to start suction (Part 1, Section 4.1).
- Check that the white voltage indicator light (Part 3, Section 4.1) is on.
- Press the green button (Part 6, Section 4.1) to start suction.
- Check that the direction of fan rotation is as indicated by the arrow in the figure.





- Press the red button (Part 7, Section 4.1) to stop the vacuum cleaner
- Press the red button (Part 2, Section 4.1) in case of EMERGENCY
- If the direction of rotation of the motor is incorrect, simply insert a screwdriver into the notch inside the power plug and reverse two poles with a 180° rotation (for versions and models where provided).



- Turn the switch from I to O to stop suction (Part 1, Section 4.1).

WARNING

Before turning on the vacuum cleaner again, make sure the pump has stopped completely.

WARNING

Avoid stepping on, crushing, pulling or damaging the mains connection cable during operation. Avoid disconnecting the cable from the mains only by pulling the plug (do not pull the cable itself). When replacing the mains cable, replace it only with one of the same type as the original one installed. Replacement must be done by the manufacturer or equivalent qualified personnel.

Those responsible for plant safety must ensure that:

- Any improper use or maneuvering be avoided.
- Safety devices are not removed or tampered with.
- Regular maintenance work is carried out.
- Machine parts (attachments, drilling, etc.) are not modified for any reason to fit additional devices.
- Only original Depureco spare parts should be used.
- Be prevented from rolling or bending the hose during the suction operation.

WARNING

If dust is escaping from the vacuum cleaner head, the filter may have broken. In this case, the vacuum cleaner should be stopped immediately.



4.3. AIR SPEED CONTROL

A vacuum gauge is mounted on the side of the device to indicate the degree of depression inside the vacuum cleaner. As the depression increases, there is a proportional reduction in suction power. If the depression reaches 220 mbar, immediate action should be taken.

- Check the hose and/or suction accessory for clogging and eliminate the cause of clogging.
- Perform a filter cleaning cycle (Ch. 4.4).
- Stop work and replace filters.

WARNING

Do not use the vacuum cleaner with a clogged filter.


4.4. FILTER CLEANING CYCLE

It is advisable to perform a filter cleaning cycle every 20 minutes of use or if you experience a drop in performance.

PUMA 10 - PUMA 12 - PUMA 15 P - PUMA 15 S - PUMA 18 P - PUMA 18 S - PUMA 20 - PUMA 25 - PUMA 10 ACD - PUMA 12 ACD - PUMA 15 P ACD - PUMA 15 S ACD - PUMA 18 P ACD - PUMA 18 S ACD - PUMA 20 ACD - PUMA 25 ACD - PUMA 10 DEX 1/3D - PUMA 15 DEX 1/3D - PUMA 20 DEX 1/3D - PUMA 25 DEX 1/3D - PUMA 10 DEX 1/2D - PUMA 15 DEX 1/2D - PUMA 20 DEX 1/2D - PUMA 25 DEX 1/2D

To perform a filter cleaning cycle:

- Turn off the machine.
- Wait for the impellers of the motors to come to a complete stop.
- Shake the filter by energetically operating the filter shaking lever (Q) from right to left.





CLEANING OPTION SP - CARTRIDGES IN AIR CONTROCORRENT

PUMA 10 SP - PUMA 15 P SP - PUMA 15 S SP - PUMA 18 P SP - PUMA 18 S SP - PUMA 20 SP - PUMA 25 SP - PUMA 30 P SP - PUMA 30 S SP - PUMA 35 P SP - PUMA 35 S SP - PUMA 10 SP DEX 1/3D - PUMA 15 SP DEX 1/3D - PUMA 20 SP DEX 1/3D - PUMA 25 SP DEX 1/3D - PUMA 10 SP DEX 1/2D - PUMA 15 SP DEX 1/2D - PUMA 20 SP DEX 1/2D - PUMA 25 DEX 1/2D

With the SP system, cleaning is done automatically and continuously while the filter is in use.

PUMA 30 P DEX 1/3D - PUMA 30 S DEX 1/3D -

PUMA 30 P DEX 1/2D - PUMA 30 S DEX 1/2D

With the SP system, cleaning is done automatically and continuously while the filter is in use.

"CLEAN" OPTION - ELECTRIC FILTER SHAKER

PUMA 30 P - PUMA 30 S - PUMA 35 P - PUMA 35 S

PUMA 30 P ACD - PUMA 30 S ACD - PUMA 35 P ACD - PUMA 35 S ACD

To perform a filter cleaning cycle with the SE system, proceed as follows:

- Turn off the machine Turning the disconnecter from I a O.
- Wait for the engine to come to a complete stop.
- To perform cleaning, press and hold the appropriate button on the control panel. When the button is released, cleaning stops.



PSC CLEANING OPTION - PNEUMATIC SCUFFLER

PUMA 10 - PUMA 15 P - PUMA 15 S - PUMA 18 P - PUMA 18 S - PUMA 20 - PUMA 25 - PUMA 30 P - PUMA 30 S - PUMA 35 P - PUMA 35 S - PUMA 10 ACD - PUMA 15 P ACD - PUMA 15 S ACD - PUMA 18 P ACD - PUMA 18 S ACD - PUMA 20 ACD - PUMA 25 ACD - PUMA 30 P ACD - PUMA 30 S ACD - PUMA 35 P ACD - PUMA 35 S ACD

To perform a filter cleaning cycle with the PSC system, proceed as follows:

- Turn off the machine Turning the disconnecter from I a O.
- Wait for the engine to come to a complete stop.
- To perform cleaning, press and hold the appropriate button on the control panel. When the button is released, cleaning stops.

ALL MODELS

If the vacuum cleaner does not work properly after filter cleaning, the main filter may need to be replaced (see dedicated chapter). If the vacuum is not significantly reduced by replacing the filter, it means that another problem is present (see chapter "If something is not working").

WARNING

Do not use the vacuum cleaner with a clogged filter.

4.5. EMPTYING THE CONTAINER

WARNING

The container/Endless Bag should not only be emptied when full, but also at the end of each work cycle and before being transported. During this operation, use the appropriate PPE (gloves, dust mask, goggles, etc.).


WARNING

Depending on the type of material vacuumed and the amount, the debris container/Endless Bag should be checked periodically and overfilling should be avoided.

WARNING

Before proceeding with emptying, turn off the machine and lock the vacuum cleaner using the lever on the swivel wheel (Section 4.23).

- Unlock the container by raising the appropriate lever (Part 10, Section 1.2).





- Remove the container (Part 5, Section 1.2) from under the chamber.



- Empty the container into the receptacle intended for waste disposal in accordance with the laws of the country of use.



- In case of using a plastic bag for debris collection, after removing the container, tie the bag, pull it out and insert a new bag.



 **WARNING**

If the container weighs more than 15 kg, you need to get help from another person.

 **WARNING**

Waste disposal must be in accordance with the laws in force in the country where the vacuum cleaner is used - for Italy Legislative Decree 152/2006 as amended.

 **WARNING**

In the case of dust extraction that may give rise to self-ignition phenomena, the collection bin must be emptied immediately after each activity.

This precaution should also be taken in the case of aspiration of dust of different types whose mixture may give rise to exothermic reactions.




4.6. INSERTING AND LOCKING THE CONTAINER


- Insert the container under the vacuum cleaner, holding the lever up, until it comes to a complete stop against detentions.



- Check that the pins (A) on both sides of the container are aligned with the slots (B) of the guides.



- Lower the container locking lever completely and with both hands.



WARNING

Danger of crushing upper limbs!

Never insert your hands between the container and the vacuum cleaner during the clamping operation.

Perform the container locking operation by operating the appropriate lever with BOTH HANDS.

4.7. STORAGE - DECOMMISSIONING

Remove the filter and clean it, empty the debris collection container / Endless Bag and store the vacuum cleaner in a place sheltered from the weather with temperatures between 5° and 45°C, covering it with a nylon cloth so as to prevent dust accumulation.



5. MAINTENANCE SECTION

WARNING

Extraordinary maintenance of the vacuum cleaner should be carried out only by specialized technicians recognized by the DEPURECO dealer.

5.1. INFORMATIONAL NOTES

Maximum vacuum cleaner reliability and minimum maintenance cost are the result of a planned and scrupulously followed maintenance and inspection program throughout the life of the vacuum cleaner. It is important to:

- Strictly adhere to the established maintenance time intervals and cadence the maintenance work according to the specific needs in relation to the production cycle of the vacuum cleaner.
- Always use tools that are in perfect condition and specially made for the task at hand; the use of unsuitable and inefficient equipment can cause serious damage.
- Any other work that may be necessary to eliminate faults or malfunctions must be expressly authorized by the manufacturer.
- For major repairs, it is advisable to contact the authorized dealer whose trained staff, equipped with all the technological experience of the original factory construction, is always on call and able to take timely action.
- Disassembly, cleaning, and maintenance of the vacuum cleaner by the user should be carried out whenever possible without leading to hazards to maintenance personnel and third parties. Suitable precautionary measures include decontamination before disassembly, measures for filtered forced ventilation of the room where the unit is disassembled, cleaning of the maintenance area, and suitable personal protective equipment.
- The manufacturer or qualified person should perform, at least once a quarter (or more frequently depending on the working cycle and conditions of use), an inspection to the filters checking that they are not damaged, also check the proper functioning of the control devices.

WARNING

Following maintenance or repair work, all contaminated items that cannot be satisfactorily cleaned should be placed in waterproof bags and disposed of in accordance with applicable laws.

5.2. GENERAL SAFETY STANDARDS

WARNING

All maintenance, repair, or cleaning must be done with the plug disconnected from the power outlet (and the air disconnected for the CCA system). Appropriate PPE (protective clothing, goggles and/or gloves, etc.) must be worn depending on the work to be performed.

Affix a sign on the vacuum cleaner indicating:

"MACHINE UNDER MAINTENANCE DO NOT START"

Before resuming service, recheck the entire system in accordance with the start-up procedures. Perform a few test cycles after each maintenance operation to check that the machine is working properly. Failure to observe these precautions may result in serious injury to personnel. Maintenance work must be performed by technicians who are skilled and trained in the specific areas, which for this machine are:

- Mechanical maintenance.
- Electrical maintenance.

It is the specific duty of the **Head of Security** Ensure the professionalism and competence of the aforementioned people.

Before starting a maintenance task, the Safety Officer must:



- Have the work area cleared of outsiders.
- Make sure the necessary tools are within reach of the maintainer and are in good condition.
- Ensure that the maintenance worker has the necessary personal protective equipment for the specific operation (gloves, goggles, shoes, mask, etc.).
- Ensure that the maintainer has carefully read the instructions in this manual and is fully familiar with the operation of the vacuum cleaner and its components.
- Check for sufficient lighting and provide 24-volt powered portable lamps if necessary.

Before starting maintenance work, the Maintainer must disconnect all electrical supplies and put the vacuum cleaner in a safety lockout condition and disconnect the connection to compressed air (where applicable).

WARNING

If it is absolutely necessary to operate with the power on, when required by D. Lgs. 81/08, the maintainer must keep a safe distance, have stop buttons within reach, and never put hands in the discharge volume. At the end of the intervention and before resuming service, the maintainer must recheck the functionality of safety devices and the integrity of protections.

Work on motors or other electrical components should be performed only by the specially trained Electrical Maintenance Worker authorized by the Safety Officer.

WARNING

After each maintenance work, the Safety Officer is obliged to ensure the safe condition of the vacuum cleaner and its protective devices.

Before each work shift:

- Check that the power cord and plug are not damaged: replace it immediately if it shows signs of wear and tear, using a cord of the same type (information c/o DEPURECO) - operation the sole responsibility of an electrician.
- Check the integrity of the safety symbols (pictograms) attached to the vacuum cleaner.
- Check that the debris collection container is empty and properly locked under the vacuum cleaner.
- Verify proper filter efficiency by checking the indicator light or vacuum gauge.
- Check the integrity of the suction hose and accessories to be used.

WARNING

The hose, if perforated, decreases the suction power and disperses dust into the air.



5.3. PRIMARY FILTER REPLACEMENT


WARNING

Wear appropriate PPE (dust mask, latex gloves, goggles, etc.).


For the filter replacement primary Operate as follows:

**PUMA 10 - PUMA 15 P - PUMA 15 S - PUMA 18 P - PUMA 18 S - PUMA 20 - PUMA 25 -
PUMA 10 ACD - PUMA 15 P ACD - PUMA 15 S ACD - PUMA 18 P ACD -
PUMA 18 S ACD - PUMA 20 ACD - PUMA 25 ACD - PUMA 10 DEX 1/3D - PUMA
15 DEX 1/3D - PUMA 20 DEX 1/3D - PUMA 25 DEX 1/3D - PUMA 10
DEX 1/2D - PUMA 15 DEX 1/2D - PUMA 20 DEX 1/2D - PUMA 25 DEX 1/2D**

- Turn off the machine.
- Disconnect the vacuum cleaner from the power supply.
- Remove the container as described in Section 4.5.
- Unlock the three locking hooks (C) of the lid on the filter chamber.




- Disconnect the suction pipe (R) by unscrewing the clamp with appropriate hexagonal wrench
- Remove the cover (S) and place it on the workbench.
- Slide out the filter (D) and place it on the workbench.





- Loosen the retaining clamp (E) and detach the filter from its holder.




- Unfasten the tapes on the inside of the filter that secure it to the cage.



WARNING

Remove the filter, place it inside a plastic bag, close it and dispose of it according to current laws for the type of material sucked in.

 USE ONLY ORIGINAL DEPURECO FILTERS!


 TO REASSEMBLY THE FILTER OPERATE THE FOLLOWING OPERATIONS. ASSEMBLE THE FILTER BY INSERTING INSIDE EACH OF THE SPACES IN THE SPOKE SUPPORT, TWO OF THE FILTER POCKETS.




PUMA 30 P - PUMA 30 S - PUMA 35 P - PUMA 35 S

PUMA 30 P ACD - PUMA 30 S ACD - PUMA 35 P ACD - PUMA 35 S ACD


- Turn off the machine.
- Disconnect the vacuum cleaner from the power supply and compressed air supply.
- Unlock the three locking hooks (C) of the lid on the filter chamber.



- Disconnect the appropriate electrical connector located on the support assembly
- Remove the cover and place it on the workbench.
- Remove the filter (J) complete with support and rotational motor and place it gently on a workbench.




- Loosen the retaining clamp (E) and detach the filter from its holder.






- Unfasten the tapes on the inside of the filter that secure it to the cage.



WARNING

Remove the filter, place it inside a plastic bag, close it and dispose of it according to current laws for the type of material sucked in.

 USE ONLY ORIGINAL DEPURECO FILTERS!


 TO REASSEMBLY THE FILTER OPERATE THE FOLLOWING OPERATIONS. ASSEMBLE THE FILTER BY INSERTING INSIDE EACH OF THE SPACES IN THE SPOKE SUPPORT, TWO OF THE FILTER POCKETS.




PUMA 30 P DEX 1/3D - PUMA 30 S DEX 1/3D -

PUMA 30 P DEX 1/2D - PUMA 30 S DEX 1/2D

- Turn off the machine.
- Disconnect the vacuum cleaner from the power supply and compressed air supply.
- Unlock the three locking hooks (C) of the lid on the filter chamber.




- Disconnect the external air hoses (red).
- Lift the lid slightly.
- Disconnect the air hoses connected to the valves and tank (blue).
- Disconnect the appropriate electrical connector located on the filter cartridge support assembly (H).




- Remove the cover and place it on the workbench.
- Using an eyebolt (not included in the scope of supply) with GAS thread with G1 male connection (screw the said eyebolt to the threaded hole on the upper face of the tank (N)) and with the help of suitable equipment (belts and lifting and handling systems), lift the filter cartridge support assembly (H) and place it upside down on a workbench.



- From the base of the cartridges, remove and unscrew the retaining nuts (I).



- Slide out and replace the filter cartridges.



WARNING

Remove the cartridges, place them inside a plastic bag, close it and dispose of it according to current laws for the type of material sucked in.

 USE ONLY ORIGINAL DEPURECO CARTRIDGES!

 TO REASSEMBLE THE CARTRIDGES OPERATE THE ABOVE STEPS BACKWARD.



CLEANING OPTION SP - CARTRIDGES IN AIR CONTROCORRENT


PUMA 10 SP - PUMA 15 P SP - PUMA 15 S SP - PUMA 18 P SP - PUMA 18 S SP - PUMA 20 SP - PUMA 25 SP - PUMA 30 P SP - PUMA 30 S SP - PUMA 35 P SP - PUMA 35 S SP - PUMA 10 SP DEX 1/3D - PUMA 15 SP DEX 1/3D - PUMA 20 SP DEX 1/3D - PUMA 25 SP DEX 1/3D - PUMA 10 SP DEX 1/2D - PUMA 15 SP DEX 1/2D - PUMA 20 SP DEX 1/2D - PUMA 25 DEX 1/2D

WARNING


Wear appropriate PPE (dust mask, latex gloves, goggles, etc.).

For the **filter replacement primary** Operate as follows:

- Turn off the machine.
- Disconnect the vacuum cleaner from the power supply and compressed air supply.
- Unlock the three locking hooks (C) of the lid on the filter chamber.




- Disconnect the external air hoses (red).
- Lift the lid slightly.
- Disconnect the air hoses connected to the valves and tank (blue).
- Disconnect the appropriate electrical connector located on the filter cartridge support assembly (H).




- Remove the cover and place it on the workbench.
- Using an eyebolt (not included in the scope of supply) with GAS thread with G1 male connection (screw the said eyebolt to the threaded hole on the upper face of the tank (N)) and with the help of suitable equipment (belts and lifting and handling systems), lift the filter cartridge support assembly (H) and place it upside down on a workbench.



- From the base of the cartridges, remove and unscrew the retaining nuts (I).



- Slide out and replace the filter cartridges.



WARNING

Remove the cartridges, place them inside a plastic bag, close it and dispose of it according to current laws for the type of material sucked in.

 USE ONLY ORIGINAL DEPURECO CARTRIDGES!

 TO REASSEMBLE THE CARTRIDGES OPERATE THE ABOVE STEPS BACKWARD.



PSC CLEANING OPTION - PNEUMATIC SCUFFLER


PUMA 10 - PUMA 15 P - PUMA 15 S - PUMA 18 P - PUMA 18 S - PUMA 20 - PUMA 25 - PUMA 30 P - PUMA 30 S - PUMA 35 P - PUMA 35 S - PUMA 10 ACD - PUMA 15 P ACD - PUMA 15 S ACD - PUMA 18 P ACD - PUMA 18 S ACD - PUMA 20 ACD - PUMA 25 ACD - PUMA 30 P ACD - PUMA 30 S ACD - PUMA 35 P ACD - PUMA 35 S ACD

WARNING


Wear appropriate PPE (dust mask, latex gloves, goggles, etc.).

For the filter replacement primary Operate as follows:


- Turn off the machine.
- Disconnect the vacuum cleaner from the power supply and compressed air supply.
- Disconnect the external compressed air hoses from the cover.
- Unlock the three locking hooks (C) of the lid on the filter chamber.



- Remove the cover and place it on the workbench.
- Remove the filter (K) complete with support and plunger and place it gently on a workbench.



- Loosen the retaining clamp (E) and detach the filter from its holder.






- Unfasten the tapes on the inside of the filter that secure it to the cage.



WARNING

Remove the filter, place it inside a plastic bag, close it and dispose of it according to current laws for the type of material sucked in.

 USE ONLY ORIGINAL DEPURECO FILTERS!

 TO REASSEMBLY THE FILTER OPERATE THE FOLLOWING OPERATIONS. ASSEMBLE THE FILTER BY INSERTING INSIDE EACH OF THE SPACES IN THE SPOKE SUPPORT, TWO OF THE FILTER POCKETS.



5.4. HEPA FILTER REPLACEMENT

WARNING


Wear appropriate PPE (dust mask, latex gloves, goggles, etc.).

For the filter replacement HEPA Operate as follows:

- Turn off the machine.
- Disconnect the vacuum cleaner from the power supply.

**PUMA 10 DEX 1/2D - PUMA 15 DEX 1/2D - PUMA 20 DEX 1/2D - PUMA 25 DEX 1/2D -
PUMA 30 P DEX 1/2D - PUMA 30 S DEX 1/2D - PUMA 10 DEX 1/2D - PUMA 15
DEX 1/2D - PUMA 20 DEX 1/2D - PUMA 25 DEX 1/2D - PUMA 30 P DEX 1/2D
- PUMA 30 S DEX 1/2D**

- Unlock the three locking hooks (T) of the cover on the HEPA unit (Part 6 Section 1.2) placed on the engine cowl.
- Remove the cover (U) of the absolute filter kit.



- Slide out the HEPA cartridge by unscrewing the retaining nut

WARNING

Remove the HEPA filter, place it inside a plastic bag, close it, and dispose of it according to current laws for the type of material vacuumed.

 USE ONLY ORIGINAL DEPURECO HEPA FILTERS!


 TO REMOVE THE HEPA FILTER, DO THE FOLLOWING OPERATIONS.



HEPA FILTER OPTION

PUMA 10 - PUMA 15 P - PUMA 15 S - PUMA 18 P - PUMA 18 S - PUMA 20 - PUMA 25
- PUMA 30 P - PUMA 30 S - PUMA 35 P - PUMA 35 S - PUMA 10 SP - PUMA 15 P SP -
PUMA 15 S SP - PUMA 18 P SP - PUMA 18 S SP - PUMA 20 SP - PUMA 25 SP -
PUMA 30 P SP - PUMA 30 S SP - PUMA 35 P SP - PUMA 35 S SP - PUMA 10 ACD -
PUMA 15 P ACD - PUMA 15 S ACD - PUMA 18 P ACD - PUMA 18 S ACD - PUMA
20 ACD - PUMA 25 ACD - PUMA 30 P ACD - PUMA 30 S ACD - PUMA
35 P ACD - PUMA 35 S ACD - PUMA 10 DEX 1/3D - PUMA 15 DEX 1/3D - PUMA 20
DEX 1/3D - PUMA 25 DEX 1/3D - PUMA 30 P DEX 1/3D - PUMA 30
S DEX 1/3D - PUMA 10 SP DEX 1/3D - PUMA 15 SP DEX 1/3D - PUMA 20 SP DEX
1/3D - PUMA 25 SP DEX 1/3D

- Unlock the three locking hooks (T) of the cover on the HEPA unit (Part 6 Section 1.2) placed on the engine cowl.
- Remove the cover (U) of the absolute filter kit.



- Slide out the HEPA cartridge by unscrewing the retaining nut

WARNING

Remove the HEPA filter, place it inside a plastic bag, close it, and dispose of it according to current laws for the type of material vacuumed.

 USE ONLY ORIGINAL DEPURECO HEPA FILTERS!

 TO REMOVE THE HEPA FILTER, DO THE FOLLOWING OPERATIONS.



5.5. IF SOMETHING DOESN'T WORK

ANOMALY FOUND	POSSIBLE CAUSE	RECOMMENDED REMEDY
The vacuum cleaner does not start.	Lack of power supply.	<ul style="list-style-type: none">• Check for the presence of voltage in the power outlet.• Check the integrity of the plug and power cord.• Contact DEPURECO technical assistance.
Red light on or vacuum gauge indicating irregular vacuum (Section 4.3).	Clogged filter.	<ul style="list-style-type: none">• Shake the filter.• If it is not enough, replace it.
Dust leakage from the vacuum cleaner.	<ul style="list-style-type: none">• Filter washed out.• Filter not suitable for the type of material to be vacuumed.	<ul style="list-style-type: none">• Replace the filter.• Mount the filter suitable for the material to be vacuumed.
Excessively noisy engines.	Failed engines.	Contact DEPURECO technical assistance.


5.6. SCRAPPING

WARNING

In case of scrapping, to avoid damage to the environment, all vacuum cleaner components, shall be disposed of responsibly, in appropriate landfills following the relevant national regulations. Vacuum cleaner parts consisting of plastic material, aluminum, steel, may be recycled by delivering them to the appropriate centers.

The crossed-out bin symbol on the label on the equipment indicates that it complies with the regulations on waste electrical and electronic equipment. Abandoning the equipment in the environment or improperly disposing of it is punishable by law.

RAEE REGISTER ENTRY NO. IT18090000010711





MAINTENANCE LOG

MODEL: _____

MATRICOLA: _____

DELIVERY DATE: _____

ENTERPRISE: _____

ADDRESS: _____

N. _____

CITY: _____

ZIP CODE: _____

BUSINESS SECTOR: _____

PHONE: _____

RESPONSIBLE: _____

TIMBERS: _____

Depureco Industrial Vacuums Srl

Company subject to management and coordination COFISE spa

Via Venezia, 32 - 10088 Volpiano (TO)
Tel. +39 011 98.59.117
Fax. +39 011 98.59.326

www.depureco.com
depureco@depureco.com
depureco@documentipec.com

C.F. and P.I. 02258610357 - **Capital stock:** € 25,000 i.v.
Turin Business Register - **R.E.A.** TO-1149668
Registration **WEEE** No. IT18090000010711



INTERVENTION 1:

DATE:

TECHNICAL ASSISTANCE:

TYPE OF INTERVENTION:

INTERVENTION 2:

DATE:

TECHNICAL ASSISTANCE:

TYPE OF INTERVENTION:

Depureco Industrial Vacuums Srl

Company subject to management and coordination COFISE spa

Via Venezia, 32 - 10088 Volpiano (TO)
Tel. +39 011 98.59.117
Fax. +39 011 98.59.326

www.depureco.com
depureco@depureco.com
depureco@documentipec.com

C.F. and P.I. 02258610357 - **Capital stock:** € 25,000 i.v.
Turin Business Register - **R.E.A.** TO-1149668
Registration **WEEE** No. IT18090000010711



INTERVENTION 3:

DATE:

TECHNICAL ASSISTANCE:

TYPE OF INTERVENTION:

INTERVENTION 4:

DATE:

TECHNICAL ASSISTANCE:

TYPE OF INTERVENTION:

Depureco Industrial Vacuums Srl

Company subject to management and coordination COFISE spa

Via Venezia, 32 - 10088 Volpiano (TO)
Tel. +39 011 98.59.117
Fax. +39 011 98.59.326

www.depureco.com
depureco@depureco.com
depureco@documentipec.com

C.F. and P.I. 02258610357 - **Capital stock:** € 25,000 i.v.
Turin Business Register - **R.E.A.** TO-1149668
Registration **WEEE** No. IT18090000010711

